## Electrostatic Filter Cleaning & Maintenance


STEP 1

Remove the Electrostatic Filter from your unit...it installs and removes just like a disposable air filter.



STEP 2

Simply backwash (see arrow on filter) with a garden hose... a mild degreaser can be used if desired.



Shake out moisture

and re-install. You're done! For optimum performance, clean your Electrostatic Filter at least

once-a-month.

STEP 3

Vacuum the Electrostatic Filter from the front once-a-month for maximum protection.

